



REPAIR PARTS LIST

KENMORE CLASSIC® ELECTRIC RANGE

MODEL NOS.

363.9858810
(External Vented)
363.9868810
(Recirculation Vent)

The Model Number will be found on a plate attached to the Upper Right Corner of the Front Frame. To locate plate, open Lower Oven Door. Always mention the Model Number when requesting service or repair parts for your Range.

All parts listed herein may be ordered from any Sears, Roebuck and Company retail or catalog store.

HOW TO ORDER REPAIR PARTS


WHEN ORDERING REPAIR PARTS, ALWAYS GIVE THE FOLLOWING INFORMATION:

- | | |
|---------------------|------------------|
| 1. PART NUMBER | 4. COLOR OF ITEM |
| 2. PART DESCRIPTION | 5. NAME OF ITEM |
| 3. MODEL NUMBER | Classic® Range |

If the parts you need are not stocked locally, your order will be electronically transmitted to a Sears Repair Parts Distribution Center for expedited handling.

SEARS, ROEBUCK AND CO. U.S.A.


MODELS 363.9858810, 363.9868810 **HOOD PARTS**



CAUTION: Use the part number on all orders, not the illustration number.

REF. NO.	PART NO.	PART DESCRIPTION	REF. NO.	PART NO.	PART DESCRIPTION
1	S594000 SR4000 SR4102	GUIDE OWNERS MINI MANUAL REPLACEMENT PARTS	883	WB07X0770 WB07X0771	END CAP RH END CAP LH
148	WZ04X0237	SCREW	884	WB02X3432	PAD
851	WB26X5083	BLOWER MOTOR	885	WB02X2017	COVER BACK
856	WB02X7764	DAMPER (363.9858810)	885	WB02X3131	SPRING & PIN ASM
864	WB56X6074 WB56X6076	HOOD BODY (WHITE) HOOD BODY (ALMOND)	902	WB49X5391	PLENUM AIR
871	WB02X7758	FILTER GREASE	916	WB02X7759	COVER
872	WB02X1583	CLIP HOOD FILTER	936	WB02X7692	FILTER COMBINATION (363.9868810)
873	WB15X0109	HANDLE HOOD PANEL	940	WB02X7760	COVER HOUSING
875	WB49X5935	EXHAUST ASM (363.9858810)	993	WB02X7765	PLATE (363.9858810)
880	WB56X0923	PANEL HOOD			
881	WB02X7776	PLATE FILTER			
882	WB07X6793	TRIM HOOD			


MODELS 363.9858810, 363.9868810 **LATCH MECHANISM PARTS**



CAUTION: Use the part number on all orders, not the illustration number.

REF. NO.	PART NO.	PART DESCRIPTION
700	WB14X5036	LATCH
701	WB15X5133	HANDLE LATCH
702	WB03X5681	KNOB LATCH
703	WB02X2030	RETAINER KNOB
704	WB02X7707	CHANNEL LATCH
705	WB02X7710	CHANNEL
706	WB02X7708	PAWL LOCKING
	WB02X7746	LOCKING PAWL
707	WB02X7709	PLATE MOUNTING
708	WB24X0183	SWITCH LATCH
709	WB24X0197	SOLENOID
710	WB09X0148	SPRING
711	WB02X6212	PIVOT STUD
712	WB02X1800	RETAINER RING
731	WB02X7711	BRACKET SWITCH
732	WB24X5235	SWITCH


MODELS 363.9858810, 363.9868810 CONTROL PANEL PARTS



CAUTION: Use the part number on all orders, not the illustration number.

**MODELS 363.9858810, 363.9868810
CONTROL PANEL**


REF. NO.	PART NO.	PART DESCRIPTION
3	WB21X5243	SWITCH, INF SURFACE UNIT
4	WB03X5717	KNOB SURFACE UNIT
5	WB02X1608	NEON LAMP 118V
11	WB22X0079	SWITCH OVEN UPPER OVEN
	WB22X5103	SWITCH OVEN LOWER OVEN
12	WB03X5715	KNOB OVEN SWITCH UPPER OVEN
	WB03X5718	KNOB OVEN SWITCH LOWER OVEN
14	WB21X5208	THERMOSTAT UPPER OVEN
	WB21X0184	THERMOSTAT, DUAL LOWER OVEN
	WB02X6274	SLEEVE CAP TUBE
15	WB03X5716	KNOB THERMOSTAT UPPER OVEN
	WB03X5719	KNOB THERMOSTAT LOWER OVEN
16	WB19X5293	TIMER
17	WB03X5699	KNOB TIMER
18	WB36X5632	CRYSTAL
	WB02X3232	PAD CRYSTAL SHORT
	WB02X6240	PAD CRYSTAL LONG
27	WB02X2900	SPACER
39	WB02X3243	BRACKET LAMP
45	WB01X0540	NUT
782	WB17X5060	TERMINAL BLK ASM 2 PIN
788	WB17X5064	HOUSING SOCKET PKG 4 PIN
828	WZ04X0367	SCREW
829	WB02X0190	CLIP SPRING
830	WB02X3463	SPACER
923	WB07X1223	TRIM CONTROL
925	WB07X0985	TRIM SWITCH
926	WB02X3196	BRACKET INSTRUMENT
927	WB02X2657	BRACKET THERMO UPPER
	WB02X6455	BRACKET THERMO LOWER
928	WB02X2966	BRACKET SWITCH
929	WB24X0177	SWITCH LAMPS
930	WB24X0178	SWITCH FAN
931	WB02X2470	EXT SHAFT UPPER THERMO
	WB02X3219	EXT SHAFT LOWER THERMO
932	WB01X0358	SPEED NUT

**MODELS 363.9858810, 363.9868810
UPPER OVEN PARTS****CAUTION:** Use the part number on all orders, not the illustration number.

MODELS 363.9858810, 363.9868810 UPPER OVEN

REF. NO.	PART NO.	PART DESCRIPTION	REF. NO.	PART NO.	PART DESCRIPTION
279	WB08X0191	RECEPTACLE	907	WB02X1666	FILTER
280	STD372401	LAMP 40W APPLIANCE	908	WB44X0195	BAKE UNIT 208/240V
290	WB24X5239	SWITCH, THERMAL FAN	909	WB44X0139	BROIL UNIT 208/240V
305	WB02X6653	SPEED NUT	911	WB15X5165	HANDLE
456	WZ04X0209	SCREW HANDLE	912	WB01X5508	STRIKE ASM DOOR
522	WB02X6209	CLIP TRIM	913	WB55X0421	BOTTOM CASE
763	WB02X1665	CLIP FILTER	915	WB55X0198	GUARD INSULATION LOWER
789	WB27X5271	RELAY	917	WB56X5768	FRAME
827	WB02X2999	ANGLE BRACE	918	WB07X0776	DEFLECTOR
886	WB53X5109	OVEN LINER	919	WB01X0529	PIN HINGE
	WB02X1511	INSULATION			
	WB02X3471	CLIP CAPILLARY TUBE OVEN	920	WB49X5463	COVER BACK
887	WB48X0090	RACK OVEN	921	WB02X2785	GUIDE DOOR
888	WB49X5464	REFLECTOR	922	WB02X1570	CATCH SPRING
889	WB49X0301	COVER INSTRUMENT	933	WB02X1667	CLIP
890	WB56X6056	PANEL ASM LH	978	WB02X1126	PLUG BUTTON
	WB56X6057	PANEL ASM RH			
891	WR62X0043	CAPACITOR			
892	WB56X6058	PANEL BOTTOM			
893	WB56X6059	PANEL REAR			
894	WB56X6082	DOOR OVEN			
895	WB02X1658	PLATE FRICTION			
896	WB01X0400	SCREW			
897	WB01X0401	WASHER			
898	WB49X0179	DUCT AIR			
899	WB55X5323	GUARD INSULATION			
900	WB02X2957	GASKET SILICONE			
901	WB55X5324	GUARD INSULATION TOP			
903	WB02X1520	SHIELD OVEN LAMP			
904	WB36X0126	GLASS OVEN LAMP			
905	WB02X1509	SUPPORT BROIL			
906	WB56X1456	CASE SIDE RH (WHITE)			
	WB56X1460	CASE SIDE RH (ALMOND)			
	WB56X1461	CASE SIDE LH (WHITE)			
	WB56X1465	CASE SIDE LH (ALMOND)			

MODELS 363.9858810, 363.9868810
COOKTOP PARTS




CAUTION: Use the part number on all orders, not the illustration number.

MODELS 363.9858810, 363.9868810 **COOKTOP**

REF. NO.	PART NO.	PART DESCRIPTION	REF. NO.	PART NO.	PART DESCRIPTION
1	WB62X5353	COOKTOP (WHITE)	867	WB49X0347	PANEL LAMP
	WB62X5355	COOKTOP (ALMOND)	868	WB07X6962	PANEL CRYSTAL RH (WHITE)
5	WB02X3468	NEON LAMP 240V		WB07X6964	PANEL CRYSTAL RH (ALMOND)
	WB02X1608	NEON LAMP 118V		WB07X6965	PANEL CRYSTAL LH (WHITE)
6	WB02X1185	CLIP MTG LAMP		WB07X6967	PANEL CRYSTAL LH (ALMOND)
7	WB25X0065	JEWEL	869	WB36X0433	CRYSTAL
9	WB07X6676	END CAP RH	870	WB08X0160	SOCKET LAMP
	WB07X6677	END CAP LH	914	WB02X7218	POST RH
21	WB49X5181	COVER BACK		WB02X7219	POST LH
26	WB07X1004	TRIM COOKTOP	934	WB07X0983	HOUSING LAMP
32	WB01X5364	SCREW	962	WB07X6935	TRIM SUPPORT RH
113	WB02X2988	CLIP TRIM		WB07X6934	TRIM SUPPORT LH
136	WB07X7004	INSERT TRIM	991	WB02X3006	CLIP TUBULAR
137	WB07X7003	TRIM & CLIP ASM			
150	WB30X5071	SURFACE UNIT 6"			
151	WB32X0052	CENTER TRIM 6" UNIT			
154	WB31X5010	PAN & RING 6" CHROME			
156	WB30X5072	SURFACE UNIT 8"			
157	WB32X0051	CENTER TRIM 8" UNIT			
158	WB31X5011	PAN & RING 8" CHROME			
160	WB17X5094	RECEPTACLE ASM			
180	WB02X7618	BRACKET MTG RECEPTACLE			
253	WB49X5389	BOX COOKTOP			
254	WB38X5039	BODY VENT			
280	STD372401	LAMP 40W APPLIANCE			
826	WB02X3001	SPACER POST			
865	WB02X6736	SUPPORT RH			
	WB02X6737	SUPPORT LH			
866	WB07X1169	COVER SUPPORT RH (WHITE)			
	WB07X1173	COVER SUPPORT RH (ALMOND)			
	WB07X1174	COVER SUPPORT LH (WHITE)			
	WB07X1178	COVER SUPPORT LH (ALMOND)			


**MODELS 363.9858810, 363.9868810
LOWER OVEN PARTS**



CAUTION: Use the part number on all orders, not the illustration number.

MODELS 363.9858810, 363.9868810 **LOWER OVEN**

REF. NO.	PART NO.	PART DESCRIPTION	REF. NO.	PART NO.	PART DESCRIPTION
250	NOT AVAIL	BODY	452	WB02X0840	SLIDE TOP
	WB02X3229	BARRIER BAKE UNIT OPENING	453	WB02X0841	SLIDE BOTTOM
251	WB56X6054	FRAME FRONT	454	WB02X6208	BUMPER
252	WB02X7864	PANEL FILLER	456	WZ04X0345	SCREW
255	WB07X0552	TRIM LATCH	457	WB56X6083	DRAWER PANEL (BLACK)
256	WB01X5516	LEVELING LEG	520	WB53X5131	OVEN LINER
258	WB39X5011	GUIDE DRAWER RH		WB02X6496	INSULATION
	WB39X5010	GUIDE DRAWER LH	522	WB02X6209	CLIP TRIM
259	WB02X0831	SLIDE GUIDE	523	WB02X7693	HOUSING RECEPTACLE
260	WB10X5092	HINGE LEVER ASM RH & LH	526	WB02X3165	HANGER
261	WB10X5090	SUPPORT HINGE RH	528	WB48X5044	RACK OVEN
	WB10X5091	SUPPORT HINGE LH	529	WB49X5380	BROIL PAN
263	WB02X6195	PIN HINGE	530	WB48X5002	BROIL PAN RACK
264	WB02X1082	RETAINER PIN HINGE	650	WB44X5082	BAKE UNIT 208/240V
265	WB02X6342	GUIDE HINGE LEVER	651	WB44X0185	BROIL UNIT 208/240V
267	WB09X5073	SPRING DOOR	652	WB02X1452	SUPPORT BROIL
268	WB29X5012	SMOKE ELIMIN & TUBE ASM	717	WB02X6911	BRACKET LATCH
272	WB17X5095	BLOCK TERMINAL POWER	989	WB01X0425	SCREW
274	WB02X1908	KNOCKOUT PLATE			
275	WB02X7774	GUARD TERMINAL			
276	WB49X5398	COVER BACK			
277	WB24X0105	SWITCH OVEN LIGHT			
279	WB08X5095	RECEPTACLE			
280	STD372401	LAMP 40W APPLIANCE			
282	WB24X5138	SWITCH THERMAL			
	WB02X6215	CLAMP HARNESS			
283	WB02X3163	GASKET			
	WB02X3164	PLATE			
292	WB01X0386	CLAMP HARNESS			
302	WB02X7694	BAIL			
303	WB36X0389	GLASS OVEN LAMP			
309	WB02X6767	HOOK WIRE			
310	WB49X5156	GUARD LOWER			
348	WB02X0646	PLATE GROUND			
386	WB15X5171	HANDLE DRAWER			
451	WB58X5005	DRAWER ASM			

**MODELS 363.9858810, 363.9868810
LOWER OVEN DOOR PARTS**

CAUTION: Use the part number on all orders, not the illustration number.

**MODELS 363.9858810, 363.9868810
LOWER OVEN DOOR**

REF. NO.	PART NO.	PART DESCRIPTION
309	WB02X6767	HOOK WIRE
350	WB55X5322	DOOR LINER
	WB02X6546	INSULATION DOOR
352	WB02X6547	GASKET DOOR
355	WB55X5331	PANEL INNER
356	WB02X6574	CLIP TRIM
357	WB01X0558	SCREW
358	WB36X5560	GLASS BLACK
359	WB07X6892	TRIM DOOR
360	WB55X5325	GUARD INSULATION
361	WB01X5735	SCREW
362	WB01X0119	WASHER
363	WB02X7616	SPACER PANEL
365	WB15X5155	HANDLE DOOR
373	WB36X5634	WINDOW
391	WB02X3052	TOGGLE
392	WB02X5217	CAM LINK
393	WB09X5083	CAM SPRING
394	WB07X6889	TRIM TOP
397	WB07X6887	END CAP ASM RH
	WB07X6888	END CAP ASM LH
	WZ04X0384	SCREW MTG END CAP
399	WB02X3285	PAD SOCKET
402	WB01X0591	SPEED NUT
403	WB02X7188	BRACKET WINDOW
404	WB36X5477	CRYSTAL WINDOW
406	WB02X6238	BRACKET DOOR
407	WB07X6913	TRIM CRYSTAL
415	WB02X7608	BRACE TOP
440	WB01X5736	SPEED NUT
441	WB02X7610	BRACE SIDE RH
	WB02X7609	BRACE SIDE LH
442	WB01X5733	FASTENER
443	WB01X5734	CLIP END CAP
456	WZ04X0345	SCREW

